







**SPLICE PLATE INSTALLATION:
PERPENDICULAR RUN ONLY**

USE SPLICE PLATE TO FASTEN TWO PLANKS ENDS TOGETHER.



- M8 FLAT WASHER
- ↑ M8-50 HEX HEAD CAP BOLT
- ↑ 12-14 x 3 SELF-DRILLING FASTENER
- ↑ 12-14 x 3 SELF-DRILLING FASTENER
- ↑ 12-14 x 3 SELF-DRILLING FASTENER
- ↑ 1/4" WASHER
- S-5 BLOCK
- ▬ 48" WIDE LEDGER ANGLE
- ▬ 48" WIDE SUPPORT PLATE FOR PERPENDICULAR RUN
- ▬ 48" WIDE SUPPORT PLATE FOR PARALLEL RUN

INSTALLATION NOTES:

1. PARALLEL RUN TO BE INSTALLED FIRST. PERPENDICULAR RUN TO ATTACH TO SIDE OF PARALLEL RUN WITH LEDGER TO AVOID TRIP HAZARD.
2. SUPPORT PLATES - SPACE NO MORE THAN 5'0" ON CENTER.
3. ATTACH PLANKS ON SUPPORT PLATES USING 3" SELF-DRILLING SCREWS AND "M" WASHER.
4. GRATING SHOULD BE BUTTED END TO END OVER SUPPORTS AND SPLICE PLATES.
5. PARALLEL RUNS MUST RUN THROUGH THE PERPENDICULAR RUNS.
6. INSTALL S-5 BLOCKS OVER SEAMS AND TIGHTEN M8 BOLTS.
7. CONSULT ROOF MANUFACTURER FOR SPECIFIC INSTRUCTIONS AND WARRANTY INFORMATION.
8. ROOFWALK PLANKS AND SUPPORTS WEIGH APPROXIMATELY 20 LBS/FT.

CONTRACTOR:
JOB/LOCATION:
DATE:
WIDTH: 36"
ROOF WALK GAUGE: 18 gauge
LENGTH PARALLEL:
LENGTH PERPENDICULAR:

METAL ROOF WALKWAYS

RW36-SS
SAFETY RAIL
ONE SIDE
NON-PITCHED

R & S MANUFACTURING
AND SALES COMPANY, INC.
3575 OLD CONEJO ROAD
NEWBURY PARK, CA 91320
PHONE 805-375-3980
FAX 805-375-3981