


**SPLICE PLATE INSTALLATION:
PERPENDICULAR RUN ONLY**
USE SPLICE PLATE TO FASTEN TWO PLANKS ENDS TOGETHER.



S-5 MINIMUM
SPACING 10'
O.C.

MB-16 BOLT

S-5 BLOCK

MAX. SUPPORT
SPACING 5'-0"
O.C.


PARALLEL RUN

SEE NOTE 1

LEDGER
12-14 x 3"
SELF-DRILLING
FASTENERS

PARALLEL RUN

MAXIMUM SUPPORT PLATE
SPACING 5'-0". LOCATE
OVER PURLINS



MB-50 BOLT

S-5 BLOCK

GRATING

PERPENDICULAR RUN

MB-50 HEX HEAD CAP BOLT

12-14 x 1-1/4"
SELF-DRILLING FASTENER

12-14 x 3"
SELF-DRILLING FASTENER

"M" WASHER

S-5 BLOCK

42" WIDE LEDGER

SPLICE PLATE

48" SUPPORT PLATE
FOR PARALLEL RUN

INSTALLATION NOTES:

1. PARALLEL RUN TO BE INSTALLED FIRST. PERPENDICULAR RUN TO ATTACH TO SIDE OF PARALLEL RUN WITH LEDGER TO AVOID TRIP HAZARD.
2. SUPPORT PLATES - SPACE NO MORE THAN 5'0" ON CENTER.
3. ATTACH PLANKS ON SUPPORT PLATES USING 3" SELF-DRILLING SCREWS AND "M" WASHER.
4. GRATING SHOULD BE BUTTED END TO END OVER SUPPORTS AND SPLICE PLATES.
5. PARALLEL RUNS MUST RUN THROUGH THE PERPENDICULAR RUNS.
6. INSTALL S-5 BLOCKS OVER SEAMS AND TIGHTEN M8 BOLTS.
7. CONSULT ROOF MANUFACTURER FOR SPECIFIC INSTRUCTIONS AND WARRANTY INFORMATION.
8. ROOFWALK PLANKS AND SUPPORTS WEIGH APPROXIMATELY 10 LBS/FT.

CONTRACTOR:
JOB/LOCATION:
WIDTH: 36"
ROOF WALK GAUGE: 18 GAUGE
LENGTH PARALLEL:
LENGTH PERPENDICULAR:

DATE:
11/14/11

METAL ROOF WALKWAYS
RW36-SS

R & S MANUFACTURING
AND SALES COMPANY, INC.
3575 OLD CONEJO ROAD
NEWBURY PARK, CA 91320
PHONE: 805-375-3980
FAX: 805-375-3981